

Model 1389 and 1589-15 Supplemental Electrical & Installation Instructions

CAUTION: Read all instructions prior to installation or servicing of this equipment. Electrical shock and/or fire may result if proper safety precautions are not taken. As with any electrical device, electrical shock or fire may result in death.

This furnishing is intended for commercial use only!

Please refer to electrical labels located in close proximity to the electrical components within the furnishing for the electrical ratings. An electrical schematic is also provided in this location to provide proper wiring instructions. A licensed electrical is required to make these connections unless the furnishing is equipped with a plug in power cord. Please review local building codes to ensure that you are in compliance with all relevant codes and restrictions.

MODEL 1389

WARNING: Risk of Electric Shock – This furnishing has connection to two power sources. Both power sources are grounded. Connect this furnishing to a properly grounded outlet. Ensure that the isolated power source ground is separate from the other power source.

MODEL 1589-15

WARNING: Risk of Electric Shock – Connect this furnishing to a properly grounded outlet.

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following

Read all instructions before using the furnishing

DANGER – To reduce the risk of electrical shock and fire:

Always disconnect the furnishing from the main power source. If the furnishing's main power source is provided from an outlet, unplug the power cord from the outlet. If not, notify an electrician or store maintenance employee to de-energize the circuit by switching the electrical breaker off.

WARNING – When de-energizing this furnishing with the circuit breaker, always test the furnishing to ensure the power has been removed from the furnishing. The circuit breaker should be locked out and tagged out to ensure only the person servicing the furnishing can re-energize the furnishing.

This furnishing has connection to two power sources. Disconnect both prior to servicing or cleaning.

Do not use attachments not recommended by the manufacturer.

DO NOT USE OUTDOORS

WARNING – To reduce the risk of burns, fire, electric shock, death, or injury to persons:

- 1) Ensure that both power sources have been disconnected from the furnishing.
- 2) This furnishing shall only be used for its intended use.
- 3) Never operate furnishing if damage has been noticed on any of the electrical devices such as damage to the power cord and/or conduit or broken plug.
- 4) Keep all electrical wires clear of excessive heat.
- 5) Never operate the furnishing if the air vents are blocked. Ensure that proper air flow is available around the electrical components.
- 6) Ensure that no equipment grounds have been altered or damaged. If the furnishing has a power cord, ensure that all prongs are still in working condition and are not bent or broken.

SAVE THESE INSTRUCTIONS FOR FURTHER REFERENCE.

USER MAINTENANCE INSTRUCTION FOR MODEL 1589-15

- 1) When cleaning this unit, disconnect both power sources prior to cleaning.
- 2) When the unit is not being used, disconnect the power source(s) and wrap cord around cord bracket on the side of the unit. Ensure that cord is not dragging on the floor
- 3) When unit is not in use, it should be stored in a location to prevent damage to the unit and the power cord(s).
- 4) Before attaching cord for use, ensure that the casters are in the locked position to prevent the furnishing from being moved while power is connected. Damage to the furnishing and power cord may result.


SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

GROUNDING INSTRUCTIONS FOR MODEL 1589-15

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electrical current to reduce the risk of electrical shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

DANGER—Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service technician if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product. If it will not fit the outlet, have a proper outlet installed by a qualified, licensed electrician.

This product is for use on a nominal 120-volt circuit and has a grounding plug that looks like the plug illustrated in sketch A. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.



Permanent Wiring Conversion Instructions

Permanent Wiring Conversion Instructions (if required, by local codes):

Some check stands may be supplied with cord connections. In localities that require permanent wiring, power cords must be removed and converted to permanent wiring by a licensed electrician. In order to convert a cord connected check stand, please follow the steps below.

- 1) Disconnect ALL incoming power sources. **WARNING** - Some check stands may contain more than one power source.
- 2) Remove the cover panels on the electrical junction boxes for each circuit.
- 3) Remove the wire nuts used to connect the leads from the power cord.
- 4) Remove the power cord from the junction box by prying out the strain relief.
- 5) Insert the permanent wiring and strain relief in the junction box.
- 6) Reconnect power leads inside junction box and secure with wire nuts.
- 7) For check stands that contain Isolated Ground, please ensure permanent wiring contains Isolated Ground conductor as well as the equipment ground.
- 8) Reattach cover panels for electrical junction boxes and reattach any access panels removed on check stand to gain access to electrical components.
- 9) Reconnect ALL incoming power sources and ensure check stand operates properly.