

CLEANING INSTRUCTIONS

To maintain the overall appearance and proper operation of your Pan-Oston units, the following cleaning intervals are recommended:

Belt Cleaning

Clean conveyor belt at least once a week with a solution of mild dish detergent and water only.

Photo Sensors

(If Applicable) Clean photo sensor lenses daily with Q-tips and common rubbing alcohol only.

Stainless Steel Surfaces

Clean with non-abrasive ammonia cleaner and rinse with clear water. Wipe dry with a soft cloth.

Caution: High-strength cleaners will damage the protective coating on the stainless steel and may make the stainless steel susceptible to corrosion.

Painted Surfaces \ Laminates \ Kydex

Clean weekly with a solution of mild dish detergent and water only.

Plexi-Glass \ Lexan

Clean with non-abrasive ammonia cleaner and rinse with clear water. Wipe dry with a soft cloth.

Scanner Edge Guard

Clean daily or as needed with a solution of mild dish detergent and water only.